Emissions Monitoring Criteria

Calculated Effective Dose Equivalent (H _e) to a Member of the Public, mrem/yr	Required Monitoring
$H_e \ge 0.1$	1. Continuously monitor emissions
	2. Identify radionuclides contributing ≥ 10% of the dose
$H_{e} < 0.1$	1. Conduct periodic, confirmatory measurements to verify
	low emissions. (Note: inventory records may be used to satisfy this requirement in some cases.)

1.0/0b02e011.pdf (6/1999)